


Sound Equipment VDB-PA



Speakers:

- Nexo Geo T
- Nexo Geo S
- Nexo CD18
- Nexo CD12
- Nexo Alpha E
- Nexo Alpha
- Nexo PS15
- Nexo PS10
- Nexo LS1200
- Nexo LS500
- Mackie Art300a (active)



Controllers:

- Nexo NX242
- Nexo PS15 TD MKII
- Nexo PS10 TD

Amps:

- Camco Vortex.6
- Crown MA5002
- Crown MA3600
- QSC MX3000
- QSC PL4.0



Consoles:

- Soundcraft Series Four (40 mono 4 stereo channels)
- Soundcraft MH3 (40 mono 4 stereo channels)
- Soundcraft MH3 (32 mono 4 stereo channels)
- Soundcraft SM20 (32 channels)
- Soundcraft E6 (6 mono 2 stereo channels)
- Soundcraft GB4 (16 channels)
- Mackie CR1604-VLZ (16 mono channels)
- Allen & Heath Wizzard 14.4.2 (10 mono 2 stereo channels)

FX:

- Lexicon PCM80
- Lexicon PCM60
- TC M3000
- TC M2000
- TC D-TWO
- Roland SDE 330
- Yamaha SPX2000
- Yamaha SPX1000
- Yamaha SPX90

**Comp/Lim/Gates:**

- Drawmer DL241
- Drawmer DS201
- Drawmer DS404
- Focusrite Compounder
- DBX 162SL

Equalizers:

- Apex GX 230
- Apex dBQZERO
- La Audio 231G SP

Microphones:

- Shure SM58 SM57 SM81 B58 B87 B57
B98 B98H B52 B91
- Sennheiser MD421 E609 E604
- Beyer CK703
- Neumann KM184
- AKG C414B
- Audio Technica AT4041 AT3035 ATM25
- DPA 4061

Wireless:

- Shure UC
- Shure ULX (with SM58 B58 B87 DPA 4061)

Di's:

- Klark Teknik
- La Audio

Multicores:

- 48-36-28-24 pairs

Others:

- X-Bow (Nexo Alpha rigging)
- Verlinde SM5
- Asl intercom

Dj:

- Pioneer DJM600
- Ecler Nuo5
- Ecler PRO40
- Technics SL1200
- Pioneer CDJ1000
- Numark CDN22

